

• **NASTAVENÍ**

• **ADJUSTMENT INSTRUCTION**

• **EINSTELLUNGSANLEITUNG**

$$q_v = k \times \sqrt{\Delta p_m}$$

TINO-D				k
				12*37
A				4,5
Suljett riviä			2	3,6
Stä gda			4	2,7
Clos d			6	2,0
			8	1,3
			10	0,6

